

Can-Am Defender Rear Bumper Installation



- 1) Remove Battle Armor Rear Bumper and hardware from box. Hardware supplied is shown below.

Contains the following: (4)- 5/16'' x 2 1/2'' hex bolts, (8) 5/16'' flat washers, and (4) 5/16''-18 Nylon insert locknut.



- 2) With a 5/16'' drill bit and using the underside frame holes as guides. Drill 4 holes through the bed.



3) Raise the bumper into location and attach using the supplied hardware.



- 4) Note the bumper will swing with the bed so oversized tires may limit how far bed will dump.